

STREAM NAME

MAP REFERENCE POINT	D. A. SQUARE MILES	FLOOD FREQUENCY				REMARKS
		010 CFS	050 CFS	0100 CFS	0500 CFS	

NEVILLE CREEK

A	12.10	1893.	3469.	4370.	7167.	@ SR 1942
B	10.90	1767.	3244.	4089.	6716.	BELOW PHILS CR.
C	3.96	906.	1694.	2148.	3578.	ABOVE PHILS CR.
D	1.88	555.	1050.	1337.	2251.	@ SR 1946

STREAM NAME

MAP  
REFERENCE  
POINT

D.A.  
SQUARE  
MILES

FLOOD FREQUENCY

Q10  
CFS

Q50  
CFS

Q100  
CFS

Q500  
CFS

REMARKS

NEVILLE CR.

MAP REFERENCE POINT	D.A. SQUARE MILES	Q10 CFS	Q50 CFS	Q100 CFS	Q500 CFS	REMARKS
A	12.10	1333.	2621.	3388.	5913.	@ SR 1942
B	10.90	1254.	2468.	3192.	5576.	BELOW PHILS CR.
C	3.95	692.	1380.	1792.	3155.	ABOVE PHILS CR.
D	1.88	448.	902.	1174.	2080.	@ SR 1946

STREAM NAME

MAP  
REFERENCE  
POINT

D.A.  
SQUARE  
MILES

92  
~~914~~  
CFS

FLOOD FREQUENCY

Q50  
CFS

Q100  
CFS

Q500  
CFS

REMARKS

NEVILLE CREEK

A  
B  
C  
D

12.10  
10.90  
3.95  
1.88

513.  
481.  
261.  
167.

0.  
0.  
0.  
0.

0.  
0.  
0.  
0.

0.  
0.  
0.  
0.

@ SR 1942  
BELOW PHILS CR.  
ABOVE PHILS CR.  
@ SR 1946

STREAM NAME

MAP REFERENCE POINT	D. A. SQUARE MILES	FLOOD FREQUENCY				REMARKS
		Q 2 CFS	Q 50 CFS	Q 100 CFS	Q 500 CFS	

NEVILLE CREEK

A	12.10	794.	0.	0.	0.	@ SR 1942
B	10.90	739.	0.	0.	0.	BELOW PHILS CR.
C	5.96	371.	0.	0.	0.	ABOVE PHILS CR.
D	1.88	223.	0.	0.	0.	@ SR 1946